



## Idling Paste 10 T 7200 for protecting ink rollers

### Application

When printing half or three-quarter webs, the temperatures in the non-image areas can increase considerably. The lack of ink transfer or the non-existent paper web prevent the heat that develops from being dissipated. This heat then leads to the diameters of the rollers increasing, which in turn causes frictional heat.

Idling Paste 10 T 7200, which is based on oils that evaporate slowly and alkyds, reduce heat generation and contribute towards protection the ink rollers.

### How to use

Pour the idling paste into the clean ink dug and conduct the print run with the dug setting and the stroke of the fount pan roller set to a minimum. At the end of the print run, clean the idling ink off the rollers with conventional roller washup solution.

#### ATTENTION

**When producing large print runs, check the paste level from time to time. If the film thickness is too thin, there is a danger of piling and possibly of damage to the rollers.**

### Classification

Code per German law on hazardous substances (GefStoffV): None

Safety Data Sheet available on request.

### How supplied

1.0-kg vacuum-sealed can